

Areometer

Instructions for Use



Antifreeze Determination of TYFOCOR® and TYFOCOR® L – Water Mixtures

Fill the liquid to be checked into the measuring cylinder and bring it to +20 °C.

Draw the areometer from the protective container and immerse it into the fluid. Make sure that the areometer does not touch neither the walls nor the bottom of the measuring cylinder. Add some more liquid if necessary.

Read off the density value (g/cm³) at the liquid level and find the corresponding freezing point as listed below.

TYFOCOR® (ethylene glycol)			TYFOCOR® L (propylene glycol)		
Density at 20 °C	TYFOCOR® % v/v	Freezing point	Density at 20 °C	TYFOCOR® L % v/v	Freezing point
1.029	20	- 9.0 °C	1.023	25	- 10 °C
1.037	25	- 12.3 °C	1.029	30	- 14 °C
1.044	30	- 16.1 °C	1.033	35	- 17 °C
1.052	35	- 20.4 °C	1.037	40	- 21 °C
1.059	40	- 25.2 °C	1.042	45	- 26 °C
1.066	45	- 30.8 °C	1.045	50	- 32 °C
1.073	50	- 37.6 °C	1.048	55	- 40 °C
1.125	100 (concentr.)	- 18.0 °C	1.055	100 (concentr.)	< - 50 °C

In order to prevent corrosion, a minimum concentration of 20 % v/v TYFOCOR® must be observed in case of TYFOCOR®/ water mixtures.

A minimum concentration of 25 % v/v must be observed for aqueous TYFOCOR® L solutions when used for cooling and standard heating purposes. In solar heating equipment, a lower application limit of 40 % v/v must be kept.



TYFOROP Chemie GmbH

Anton-Rée-Weg 7 D-20537 Hamburg Tel. ++49 (0)40 -20 94 97-0 Fax: -61 52 99 e-mail: info@tyfo.de 2/04